

### INTERNAL CORNER DETAIL

The membrane should extend up the wall as far as possible or least 150mm.

Apply Contact adhesive to the wall, roof deck and membrane. Roll the membrane to the base of the angle change. Firmly press or crease the membrane tightly in to the angle change. Roll the membrane up the wall. Use a seam roller or brush to firmly adhere the membrane sheet to the wall and roof deck.

1. A pigs ear or flap will be formed by the excess membrane on an internal corner
2. The pigs ear can be cut back to 3 inches from the corner if necessary
3. Apply Rubber Primer to the back of the flap and to the membrane on the wall.
4. When touch dry secure the flap to the wall
5. Cut an appropriate size piece of uncured flashing tape,
6. Apply Rubber Primer to the rubber membrane (NOT the uncured flashing)
7. Install uncured flashing tape over the flap to fully secure to wall up stand.
8. Install Wall Trim or lead flashing to complete the detail.

